

Technical Data Sheet

Pressure / Temperature / Humidity / Air Velocity / Airflow / Sound level

KISTOCK DATALOGGER Laboratories range : KTR350 / KTH350

Temperature / Humidity





KEY POINTS

- IP65 housing
- 100 000 measurement points
- Up to 3 recordable parameters
- 1 or 2 external inputs
- 2 configurable setpoint alarms
- Fast data download (1000 values/second)
- LCD screen with displaying of measurements and recordings
- Magnetic mounting

REFERENCES

Part number	Internal sensor	External input number	Parameters	Kits de livraison
KTR-350	no	2	Pt100 temperature Current/voltage	Basic Kistock
KTH-350-A	yes	1		Kistock + integrated thermo-hygrometry probe made of polycarbonate
KTH-350-P	no	2	Humidity and PT100 temperature Current/voltage	Kistock + remote thermo- hygrometry probe made of polycarbonate
KTH-350-I	no	2	Currentivoltage	Kistock + remote thermo- hygrometry probe made of stainless steel
KTH-350	no	2		Basic Kistock

TECHNICAL FEATURES

	KTR350	KTH350	
Units dislayed	°C, °F, mV, V, mA, A	°C, °F, %RH, mV, V, mA, A, °Ctd, °Ftd	
Accuracy	0.1 °C, 0.1 °F, 0.001 V, 0.001 mA, 0.1 A		
External input	2 Pt100 connectors	1 or 2 Pt100 connectors	
Setpoint alarms	2 setpoint alarms on each channel		
Frequency of the measurement	From 1 s to 24 h		
Working temperature	From -40 to +70 °C		
Storage temperature From -40 to +85 °C) to +85 °C	
Battery life*	5 years		

* on the basis of 1 measurement each 15 minutes at 20°C

FEATURES OF HOUSING

Dimensions

98.7 x 67.8 x 34.7mm

Weight

113 g

Display

1 line LCD screen Dimension : 45 x 47 mm

Control

2 keys: Select and OK

Material

Compatible with food industry environment ABS housing

Sides and caps made of Elastomer

Protection

IP 65

PC communication

1 digital input for male Jack connector 3.5

Digital electronics

Lacquer protected circuit board Meets RoHS standards

Battery power supply

Type lithium 3.6 V 1/2 AA

Visual alarm

2 electroluminescent diodes (green and red)

Environment

Air and neutral gases

TECHNICAL FEATURES FOR PROBES FOR KTH350

THERMO-HYGROMETRY PROBE

Hygrometry

Sensor type Measuring range	Capacitive From 0 to 100 RH
Accuracy*	Accuracy** (Repeatability, linearity, hysteresis): ±1,5%RH (from 15°C to 25 °C) Factory calibration uncertainty: ±0,88%RH Temperature dependence: ±(0,04 x (T-20)%RH (if T<15°C or T>25°C)
Response time	T _{0,63} =25 s (from 10%RH to 80%RH, Vair=2 m/s)

Temperature

Sensor type	Pt100 Class 1/3 DIN as per IEC 751
Measuring range	From -20 to +70 °C (KTH-350-A) From -20 to +120 °C (KTH-350-P) From -40 to 180 °C (KTH-350-I)
Accuracy*	KTH-350-A: From +10 to +30°C: ±0.3 °C Beyond: ±0.5°C KTH-350-P, KTH-350-I: ±0.3% of the reading value ±0.25 °C
Response time	T _{0,63} =9 s (from 10%RH to 80%RH, Vair=2 m/s)

^{*}All accuracies indicated in this document were stated in laboratory conditions and can be guaranteed for measurements carried

TECHNICAL FEATURES CABLES and PROBES for KTH350 and KTR350

TEMPERATURE PROBE (OPTIONAL)

Sensor type	Pt100 class A as per IEC 751
Measuring range	From -100 to +400 °C (according probe)
Accuracy*	Remove probe : ±0.4 of the reading ±0.3°C

CURRENT INPUT CABLE (OPTIONAL)

Measuring range	0/4-20 mA
Accuracy*	±0.2 % of the measurement ±1 µA

VOLTAGE INPUT CABLE (OPTIONAL)

•	,
Measuring range	0-10 V
Accuracy*	±0.2 % of the measurement ±1 mV

AMMETER CLAMP (OPTIONAL)

Measuring range	0-50 A / 0-100 A / 0-200 A / 0-600 A	
Accuracy*	± 1 to 2.5 % of the value displayed (according to measuring range)	

DIMENSIONS (mm) KTR350 - KTH-350-P - KTH-350-I 67,85 98,7 KTH-350-A 67,85 145.7

CONNECTIONS

External input (KTR 350, KTH-350-P et KTH-350-I)



External input (KTH-350-A)



out in the same conditions, or carried out with calibration compensation.

**As per NFX 15-113 standard and the charter 2000/2001 Hygrometers, GAL (Guaranteed Accuracy Limit) which has been calculated with a coverage factor value of 2 is ±2,88%RH between 18 and 28°C on the measuring range from 5 to 95%RH. Sensor drift is less than 1%RH/year.

RECORDER FUNCTIONS

5 recording modes

KISTOCK can record in 5 different ways:

- "Immediate" mode records values according a predefined interval.
- "Minimum", "Maximum" and "Average" record automatically the calculation of minimum, maximum or average of measured values during an interval of recording.
- "Monitoring" mode allows to get an accurate history report during error events to help troubleshooting, without stopping the measurement logging. To proceed this way, you just have to define:
- a record interval to be used whilst the readings are beyond the setpoints.
- a record interval for the values measured during each reading beyond the setpoints..

Furthermore, you can also let your KISTOCK record non-stop ("loop" recording option).

4 types dataset start

Once your recording mode has been set, you can launch your dataset :

- With a delayed start (with predefined date and time)
- · With the software
- With push-button
- With "Online" option. In this case, your datasets are directly sent, saved and displayed on your PC in real time.

6 types of dataset stop

You can stop your dataset :


- According to a date and time (if it was started the same way)
- According to a period
- According to a predefined number of recording points
- Once the storage capacity is full
- With "Stop" option of the software
- By holding "OK" key for at least 5s, if this function has been previously activated by the software

THERMOMETER FUNCTION

Once "thermometer" function is activated, KISTOCK allows you to display information as below:

- Difference of temperature between 2 external probes ("Delta T"),
- Minimum temperature
- Maximum temperature
- Hold the temperature measured ("Hold").

SCREEN



°C...Temperature in degrees Celsius °F...Temperature in degrees Fahrenheit %RH.......Relative humidity (KTH 350) td...Dew point temperature (KTH 350) V or mV Voltage expressed in V or mV A or mA Current expressed in A or mA END DAT

DATASET is finished

REC

One value is being recorded

LOG

Flashing : dataset has not started vet

Constant : data set is in progress

FULL

Slow flashing: dataset is taking 80-90% of storage capacity Fast flashing: dataset is taking 90-100% of storage capacity Constant: storage capacity filled up

12

Channel No. which is measuring

ACT

Refresh of displayed measurements

PC CONNECTIONS

Jack connector

Input for Kistock-

PC software

(3.5)

Input for PC connection

TIME

Display of measurement and recording intervals

Status of battery life: 5 levels (4 blocks + empty battery)

Flashes when only one block is remaining

MIN

Displayed values correspond to maximum and minimum values of the channels

X

Alarm action type: rising or falling action

 $abla R \, b$ flashing on the screen + flashing of LEDs : means that battery must be changed

├ ┌ ← + flashing of the green LED : detection of communication error → Press "Select" and "OK" keys to reset the instrument

 Γ + flashing of the red LED : detection of measurement error \longrightarrow Press "Select" and "OK" keys to reset the instrument

• Configuration and data processing software

KILOG software enables you to configure, save and process your data in a very simple way.

This USB cable enables you to connect your



• <u>USB interface</u>......Ref. I-KIC2

• KISTOCK-PC interface K

KISTOCK to your PC.

Ref. I-KIC2

• Complete set: soft + 1 interface......Ref. KIC2 KILOG



KILOG CFR software

KILOG CFR software is the key tool for users who requires traceability, in accordance with 21CFR-Part11 standards. Security and integrity of data are guaranteed: it is not possible to modify or tamper with the data.

•	Interface	Ref.	I-KIC2
---	-----------	------	--------

Complete set: KILOG 1CFR software + 1 interface.Ref. KIC2-CFR-N



Software is compatible with the former range of Kistock.

ACCESSORIES



KNT data collector

KNT data collector allows you to collect measurements from one or several KISTOCK directly on-site (up to 500,000 values stored). Data can be displayed and printed from the KNT or download to your PC. *Ref. KNT 300*



Printer for KNT 300 data collector Out 170

Ref. ITP



KIMO has designed a new proprietary anti-theft system with no padlock. Your system cannot be unlock or damaged : your installation is fully secured.

Ref. KAV-B



Once your KISTOCK is set on the mounting plate, insert the key to lock the mounting system.



To unlock: insert the key inside the metallic axis, and make ¼ turn.



Remove the key to release the metallic axis. Your KISTOCK is now unlocked.

• Wire extensions for NTC temperature probe.

Made of PVC HT, 5m long, with Jack connectors (male and female) Ref. KRC 5

Note: you can connect several extensions together (maximum length 25m)

- · Lace. Ref. KDC
- Lithium 1/2 AA battery. Ref. KBL

CALIBRATION (Optional)

KISTOCK dataloggers can be supplied with calibration certificate as an option.

www.kimo.fr

Distributed by:

AIF AQ

EXPORT DEPARTMENT


Tel: +33. 1. 60. 06. 69. 25 - Fax: +33. 1. 60. 06. 69. 29

e-mail: export@kimo.fr

MOUNTING

KISTOCK can be mounted in different ways you can also move it or install it very easily.

- Magnetic mounting or wallmounting (see photos)
- Secured mounting (optional, see accessories)



HOW TO CHANGE THE BATTERY

With 5-year battery life*, KISTOCK guarantee long-term measurements.

To change battery:

- Remove the screw located at the back, with a screw driver.
- Remove the front part, along with the old battery.
- Insert the new battery observing the proper polarity
- Replace the front.
- Tighten the screw.
- Press "SELECT" and "OK" keys for 2 seconds to refresh battery level.
- * on the basis of 1 measurement each 15 minutes at 20°C

WARRANTY PERIOD

KISTOCK dataloggers have 1-year guarantee for any manufacturing defect (return to our After-Sales Service required).

PRC Technologies Corp., Ltd.

Tel: 02 530 1714, 02 530 1619, 02 530 1621

Fax: 02 530 1731

Email: info@prctechth.com, www.prctechth.com